

No.	SERIES	端末名	備考
1	FOMA 703	F703i	
2		SH703i	
3	FOMA 704	D704i	
4		F704i	
5		SH704i	
6	FOMA 705	D705i	
7		D705iμ	
8		F705i	
9		N705i	
10		N705imyu	
11		P705i	
12		P705iCL	
13		P705imyu	
14		SH705i	
15		SH705iII	
16	SO705i		
17	FOMA 706	F706i	
18		N706i	
19		N706iII	
20		N706ie	
21		P706ie	
22		P706imyu	
23		SH706i	
24		SH706ie	
25		SH706iw	
26		SO706i	
27	FOMA 8xx	F801i	
28	FOMA 903	D903i	
29		D903iTV	
30		F903i	
31		F903iX	
32		N903i	
33		SH903i	
34		SH903iTV	
35	FOMA 903	D903i	
36		D903iTV	
37		F903i	
38		F903iX	
39		N903i	
40		SH903i	
41		SH903iTV	
42	FOMA 904	D904i	
43		F904i	
44		N904i	
45		SH904i	

No.	SERIES	端末名	備考
46	FOMA 905	D905i	
47		F905i	
48		N905i	
49		N905imyu	
50		P905i	
51		P905iTV	
52		SH905i	
53		SH905iTV	
54		SO905i	
55		SO905iCS	
56	FOMA 906	F906i	
57		N906i	
58		N906iL	
59		N906imyu	
60		P906i	
61		SH906i	
62		SH906iTV	
63	SO906i		
64	A-series	F-01A	
65		F-02A	
66		F-03A	
67		F-04A	
68		F-08A	
69		F-09A	
70		L-04A	
71		L-06A	
72		N-01A	
73		N-02A	
74	N-03A		
75	N-04A		
76	N-05A		
77	N-06A		
78	N-07A		
79	N-08A		
80	N-09A		
81	P-01A		
82	P-02A		
83	P-03A		
84	P-04A		
85	P-05A		
86	P-06A		
87	P-07A		
88	P-08A		
89	P-09A		
90	P-10A		

No.	SERIES	端末名	備考
91	A-series	SH-01A	
92		SH-02A	
93		SH-03A	
94		SH-04A	
95		SH-05A	
96		SH-06A	
97		SH-06A NERV	
98		SH-07A	
99		SH-08A	
100	B-series	F-01B	
101		F-02B	
102		F-03B	
103		F-04B	
104		F-06B	
105		F-07B	
106		F-08B	
107		L-01B	
108		L-02B	
109		L-03B	
110	L-04B		
111	N-01B		
112	N-02B		
113	N-03B		
114	N-04B		
115	N-05B		
116	N-06B		
117	N-07B		
118	N-08B		
119	P-01B		
120	P-02B		
121	P-03B		
122	P-04B		
123	P-05B		
124	P-06B		
125	P-07B		
126	SH-01B		
127	SH-02B		
128	SH-03B		
129	SH-04B		
130	SH-05B		
131	SH-06B		
132	SH-07B		
133	SH-08B		
134	SH-09B		
135	C-series	CA-01C	

No.	SERIES	端末名	備考
136	C-series	F-01C	
137		F-02C	
138		F-03C	
139		F-04C	
140		F-05C	
141		F-07C	
142		F-09C	
143		F-10C	
144		F-11C	
145		L-01C	
146	L-10C		
147	N-01C		
148	N-02C		
149	N-03C		
150	N-05C		
151	P-01C		
152	P-02C		
153	P-03C		
154	P-04C		
155	P-05C		
156	P-06C		
157	SH-01C		
158	SH-02C		
159	SH-04C		
160	SH-05C		
161	SH-06C		
162	SH-08C		
163	SH-10C		
164	SH-11C		
165	D-series	F-02D	
166		F-04D	
167		F-06D	
168		N-02D	
169		N-03D	
170	P-03D		
171	SH-03D		
172	SH-05D		
173	E-series	F-01E	
174		N-01E	
175		P-01E	
176		SH-03E	

No.	SERIES	端末名	備考
1	Win 4x	W41SH	
2		W43SA	
3		W44S	
4	Win 5x	W51CA	
5		W51H	
6		W51K	
7		W51S	
8		W51SA	
9		W51SH	
10		W51T	
11		W52CA	
12		W52K	MEDIA SKIN
13		W52H	
14		W52P	
15		W52S	
16		W52SA	
17		W52SH	
18	W52T		
19	W53CA		
20	W53H		
21	W53K		
22	W53S		
23	W53SA		
24	W53T		
25	W54S		
26	W54SA		
27	W54T		
28	W55SA	INFOBAR2	
29	W55T		
30	W56T		
31	Win 6x	W61CA	
32		W61H	
33		W61K	
34		W61P	
35		W61PT	
36		W61S	
37		W61SA	
38		W61SH	
39		W61T	
40		W62CA	
41		W62H	
42		W62P	
43		W62S	
44		W62SA	
45		W62SH	

No.	SERIES	端末名	備考
46	Win 6x	W62T	
47		W63CA	
48		W63H	
49		W63S	re
50		W63SA	
51		W63SH	URBANO
52		W64S	
53		W64SA	
54		W64SH	
55		W64T	
56	W65K		
57	W65T		
58	W65S	Xmini	
59	W63T	Sportio	
60	x000/ NS/iida	F001	
61		CA001	
62		CA002	
63		CA003	
64		CA004	
65		CA005	
66		CA006	
67		CA007	
68		CAY01	G'zOne TYPE-X
69		H001	
70		HIY01	Mobile Hi-Vision CAM Wooo
71		HIY02	beskey
72		K001	
73		K002	
74		K006	
75	K007		
76	K009		
77	K011		
78	KYX02	misora	
79	KYX03	PRISMOID	
80	KYX04	lotta	
81	KYX01	NS01	
82	PTX01	NS02	
83	P001		
84	PT002		
85	PT003		

No.	SERIES	端末名	備考
86	x000/ NS/iida	S001	
87		S002	
88		S003	
89		S004	
90		S005	
91		S006	
92		S007	
93		SA001	
94		SA002	
95		SH001	
96		SH002	
97		SH003	
98		SH004	
99		SH005	
100		SH006	
101		SH007	
102		SH008	
103		SH009	
104		SH010	
105		SH011	
106		SHY01	Sportio water beat
107		SOX01	G9
108		SOX02	G11
109		SOY01	Premier3
110		SOY02	BRAVIA Phone U1
111	SOY03	URBANO BARONE	
112	SOY04	URBANO MOND	
113	SOY05	URBANO AFFARE	
114	T001		
115	T002		
116	T003		
117	T004		
118	T005		
119	T006		
120	T007		
121	T008		
122	TSX04	PLY	
123	TSX05	LIGHT POOL	
124	TSX06	X-RAY	
125	TSY01	biblio	

No.	SERIES	端末名	備考
-----	--------	-----	----

No.	SERIES	端末名	備考
1	SHARP	004SH	
2		001SH	
3		002SH	
4		105SH	
5		109SH	
6		824SH	
7		825SH	
8		830SH	
9		830SHs	
10		831SH	
11		832SH	
12		841SH	
13		842SH	
14		921SH	
15		922SH	
16		923SH	
17		930SH	
18		931SH	
19		932SH	
20		933SH	
21		934SH	
22		935SH	
23		936SH	
24		940SH	
25		941SH	
26		942SH	
27		943SH	
28		944SH	
29		945SH	
30		945SH G Ver.GP30th	

No.	SERIES	端末名	備考
31	Panasonic	002P	002P
32		001P	001P
33		942P	942P
34		842P	842P
35		841P	841P
36		940P	940P
37		941P	941P
38		931P	931P
39		930P	930P
40		921P	921P

No.	SERIES	端末名	備考
-----	--------	-----	----

No.	SERIES	端末名	備考
-----	--------	-----	----

No.	メーカー	機種	名称
1	SHARP	SH-03C	LYNX 3D
2		SH-10B	LYNX
3		SH-12C	AQUOS PHONE
4		SH-13C	AQUOS PHONE f
5		SH-01D	AQUOS PHONE
6		SH-02D	AQUOS PHONE slider
7		SH-04D	Q-pot.Phone
8		SH-06D	AQUOS PHONE
9		SH-07D	AQUOS PHONE st
10		SH-09D	AQUOS PHONE ZETA
11		SH-10D	AQUOS PHONE sv
12		SH-01E	AQUOS PHONE si
13		SH-02E	AQUOS PHONE ZETA
14		SH-04E	AQUOS PHONE EX
15	Sony Ericsson	SO-01B	Xperia
16		SO-01C	Xperia arc
17		SO-02C	Xperia acro
18		SO-03C	Xperia ray
19		SO-02D	Xperia NX
20		SO-03D	Xperia acro HD
21		SO-04D	Xperia GX
22		SO-05D	Xperia SX
23		SO-01E	XPERIA AX
24		SO-02E	Xperia Z
25	HTC	HT-03A	HTC Magic
26	Huawei	HW-01E	Ascend

No.	メーカー	機種	名称
27	Panasonic MC	P-07C	
28		P-01D	
29		P-02D	LUMIX Phone
30		P-05D	Disney Mobile on docomo
31		P-04D	
32		P-06D	ELUGA V
33		P-07D	ELUGA power
34		P-08D	ELUGA Live
35		P-02E	ELUGA X
36		富士通	F-12C
37	T-01D		REGZA Phone
38	T-02D		REGZA Phone
39	F-03D		ARROWS kiss
40	F-05D		ARROWS X LTE
41	F-07D		ARROWS μ
42	F-08D		Disney Mobile on docomo
43	F-09D		F-09D ANTEPRIMA
44	F-10D		ARROWS X
45	F-11D		ARROWS Me
46	F-12D		らくらくスマートフォン
47	F-02E		ARROWS X
48	F-03E		ARROWS Kiss
49	F-04E		ARROWS V
50	F-01D		ARROWS Tab LTE
51	富士通東芝MC	T-01C	REGZA Phone

No.	メーカー	機種	名称
52	LG Electronics	L-04C	Optimus chat
53		L-07C	Optimus bright
54		L-01D	Optimus LTE
55		L-06C	Optimus Pad
56		L-05D	Optimus it
57		L-06D	Optimus Vu
58		L-06DJOJO	Optimus Vu
59		L-01E	Optimus G
60		L-02E	Optimus LIFE
61		NECカシオMC	N-04C
62	N-06C		MEDIAS WP
63	N-01D		MEDIAS PP
64	N-04D		MEDIAS LTE
65	N-05D		MEDIAS ES
66	N-07D		MEDIAS X
67	N-02E		MEDIAS U
68	N-03E		Disney Mobile on docomo
69	N-04E		MEDIAS X
70	N-06D		MEDIAS TAB
71	SAMSUNG ELECTRONICS	SC-02B	GALAXY S
72		SC-02C	GALAXY S II
73		SC-03D	GALAXY S II LTE
74		SC-04D	GALAXY NEXUS
75		SC-01D	GALAXY Tab 10.1 LTE
76		SC-05D	GALAXY Note
77		SC-06D	GALAXY S III
78		SC-02E	GALAXY Note II
79		SC-03E	GALAXY S III α

No.	メーカー	機種	名称
-----	------	----	----

au android

No.	メーカー	機種	名称
1	SHARP	CDMA SHI01	IS01
2		CDMA SHI03	IS03
3		CDMA SHI05	IS05
4		IS11SH	AQUOS PHONE
5		IS12SH	AQUOS PHONE
6		CDMA SHX11	INFOBAR A01
7		IS13SH	AQUOS PHONE
8		IS14SH	AQUOS PHONE
9		CDMA SHX12	INFOBAR C01
10		ISW16SH	AQUOS PHONE SERIE
11		IS15SH	AQUOS PHONE SL
12		IS17SH	AQUOS PHONE CL
13		SHL21	AQUOS PHONE SERIE
14	NECカシオMC	IS11N	MEDIAS BR
15		IS11CA	G'zOne
16	CAL21	G'zOne TYPE-L	
17	京セラ	ISW11K	DIGNO
18		CDMAKY04	URBANO PROGRESSO
19	KYL21	DIGNO S	
20	富士通	ISW11F	ARROWS Z
21		IS04	REGZA Phone
22		IS12F	ARROWS ES
23		ISW13F	ARROWS Z
24	FJL21	ARROWS ef	

No.	メーカー	機種	名称
25	モトローラ モビリティ	TBi11M	MOTOROLA XOOM Wi-Fi
26		ISW11M	MOTOROLA PHOTON
27		IS12M	MOTOROLA RAZR
28	Sony Ericsson	IS11S	Xperia acro
29		IS12S	Xperia acro HD
30		SOL21	Xperia VL
31	Pantech	IS06	SIRIUS α
32		IS11PT	MIRACH
33		PTL21	VEGA
34	HTC	ISW11HT	HTC EVO WiMAX
35		ISW12HT	HTC EVO 3D
36		ISW13HT	HTC J
37		H TL21	HTC J butterfly
38		CDMAHTX21	INFOBAR A02
39	SAMSUNG	ISW11SC	GALAXY S II WiMAX
40		SCL21	GALAXY S III Progre
41	Gエレクトロニク	LGL21	Optimus G

softbank android

No.	メーカー	機種	名称
1	SHARP	003SH	GALAPAGOS
2		005SH	GALAPAGOS
3		006SH	AQUOS PHONE
4		007SH	AQUOS PHONE
5		009SH	AQUOS PHONE
6		101SH	AQUOS PHONE
7		102SH	AQUOS PHONE
8	HTC	001HT	HTC Desire HD
9	DELL	DELL Streak 001DL	

No.	メーカー	機種	名称
-----	------	----	----